



HOW TO APPLY DANISH OIL

MATERIALS NEEDED

- tmbr Danish Oil
- Clean, lint-free cloth(s)
- Fine sandpaper (180-220 grit)
- Clean cloth or vacuum
- Disposable gloves
- Fine steel wool (0000 grade, optional)

STEP 1: PREPARE THE WOOD

1. Sand the wood to a smooth finish, working your way up to 180-220 grit sandpaper.
2. Remove all dust using a vacuum, brush, or cloth.
3. Ensure the surface is clean and completely dry.

STEP 2: APPLY THE FIRST COAT

4. Stir the Danish Oil thoroughly. Do not shake it.
5. Apply a generous coat in the direction of the grain.
6. Ensure the surface is evenly wet.

STEP 3: LET THE OIL PENETRATE

7. Allow the oil to soak in for 15-30 minutes.
8. Reapply to dry areas as needed.



STEP 4: WIPE OFF EXCESS OIL

9. Wipe away all excess oil with a clean cloth.
10. Do not leave puddles or glossy patches.

STEP 5: ALLOW TO DRY

11. Let the wood dry for 12-24 hours in a well-ventilated area.

STEP 6: APPLY ADDITIONAL COATS

12. Apply 2-4 coats for greater protection.
13. Lightly sand or use 0000 steel wool between coats, if needed.
14. Remove dust before recoating.

STEP 7: FINAL CURE

15. Allow several days for a full cure.
16. Avoid heavy use until fully cured.

TIPS FOR BEST RESULTS

- Apply in a dust-free environment.
- Work between 15°C and 30°C when possible.
- Use several thin coats rather than one heavy coat.
- For most furniture projects, 3 coats with 24 hours between coats gives best results.

SAFETY

- Keep out of reach of children.
- Flammable.
- Dispose of cloths by placing in a bucket of water for a few hours.
- Clean paintbrushes using turpentine or thinners.