



HOW TO APPLY INTERIOR HARDWAX OIL

MATERIALS NEEDED

- tmbr Interior Hardwax Oil
- Lint-free cloths or applicator pad
- Fine sandpaper (120-220 grit)
- Vacuum or tack cloth
- Buffing pad or white polishing pad (optional)
- Disposable gloves

STEP 1: PREPARE THE SURFACE

1. Sand the wood smooth to 120-220 grit.
2. Remove all dust and debris.
3. Ensure the wood is clean and dry.

STEP 2: STIR THE PRODUCT

4. Stir the oil thoroughly.
5. Do not shake the container, as this may introduce bubbles.

STEP 3: APPLY THE FIRST COAT

6. Apply a thin, even coat following the wood grain.
7. Work the product into the surface and avoid heavy buildup.
8. Cover the entire surface uniformly.

STEP 4: REMOVE EXCESS OIL

9. After a few minutes, wipe away any excess product.
10. The surface should appear even, not wet or glossy.



STEP 5: ALLOW TO DRY

11. Allow the first coat to dry for 8-12 hours. Additional coats may require longer to dry.
12. Maintain good ventilation during drying.

STEP 6: APPLY ADDITIONAL COATS

13. Apply additional thin coats in the same manner.
14. 3 to 4 thin coats are often required for an optimum finish.

STEP 7: FINAL CURE

15. Let the finish cure fully before heavy use.
16. Full curing may take several days depending on temperature and humidity.

TIPS FOR BEST RESULTS

- Apply very thin coats; excess product can lead to slow drying.
- Test on a sample piece before finishing a project.
- Best to use in temperatures of between 18 degrees and 30 degrees.

SAFETY

- Keep out of reach of children.
- Clean spills immediately.
- Flammable.
- Dispose of cloths by placing in a bucket of water for a few hours.
- Clean paintbrushes using turpentine or thinners.