



HOW TO APPLY BOILED LINSEED OIL

MATERIALS NEEDED

- tmbr Boiled Linseed Oil
- Clean lint-free cloths or brushes
- Fine sandpaper (180-220 grit)
- Protective gloves (optional)

STEP 1: PREPARE THE WOOD

1. Sand the wood to a smooth finish using 180-220 grit sandpaper.
2. Remove all dust and debris from the surface.
3. Ensure the wood is clean and dry.

STEP 2: APPLY THE FIRST COAT

4. Apply a generous coat of boiled linseed oil with a cloth or brush.
5. Work in the direction of the wood grain.
6. Allow the oil to penetrate the wood evenly.

STEP 3: LET THE OIL SOAK IN

7. Allow the oil to soak into the wood for 15 to 30 minutes.
8. Apply additional oil to any areas that absorb it quickly.

STEP 4: REMOVE EXCESS OIL

9. Wipe away all excess oil using a clean cloth.
10. Do not leave wet or glossy patches on the surface.



STEP 5: ALLOW TO DRY

11. Allow the first coat to dry thoroughly, typically 24 to 48 hours.
12. Provide adequate ventilation during drying.

STEP 6: APPLY ADDITIONAL COATS

13. Apply 2 to 3 additional thin coats if a richer finish is desired.
14. Wipe away excess oil after each coat.
15. Allow sufficient drying time between coats, often a couple of days.

STEP 7: FINAL CURE

16. Allow the finish to cure completely before heavy use.
17. Full curing may take several days to several weeks depending on conditions.

TIPS FOR BEST RESULTS

- Apply multiple thin coats rather than one thick coat.
- Work in a dust-free, well-ventilated area.
- Dispose of oil-soaked rags safely, as they may spontaneously combust.
- Test the finish on a scrap piece before applying to a project.
- Regular maintenance can help preserve the appearance of the wood.