



HOW TO APPLY TEAK OIL

MATERIALS NEEDED

- tmbr Teak Oil
- Clean lint-free cloths or brushes
- Fine sandpaper (180-220 grit)
- Protective gloves (optional)

STEP 1: PREPARE THE WOOD

1. Sand the wood to a smooth finish using 180-220 grit sandpaper.
2. Remove all dust and ensure the surface is clean and dry.

STEP 2: APPLY THE FIRST COAT

3. Apply teak oil evenly with a cloth or brush.
4. Work in the direction of the wood grain.
5. Ensure the entire surface is coated.

STEP 3: ALLOW THE OIL TO PENETRATE

6. Let the oil soak into the wood for 15 to 30 minutes.
7. Apply more oil to areas that absorb it quickly.

STEP 4: WIPE AWAY EXCESS OIL

8. Use a clean cloth to remove any excess oil.
9. Do not leave wet or sticky patches on the surface.



STEP 5: ALLOW TO DRY

10. Allow the wood to dry properly, typically 12 to 24 hours.
11. Maintain good ventilation during drying.

STEP 6: APPLY ADDITIONAL COATS

12. Apply one or two additional coats for enhanced appearance and protection.
13. Allow adequate drying time between coats.

STEP 7: FINAL CURE

14. Allow the finish to cure fully before heavy use or exposure to moisture.

TIPS FOR BEST RESULTS

- Apply thin coats for more even penetration.
- Test the finish on a small hidden area first.
- Reapply periodically to maintain outdoor furniture and exposed wood.

SAFETY

- Keep out of reach of children.
- Clean spills immediately.
- Flammable.
- Dispose of cloths by placing in a bucket of water for a few hours.
- Clean paintbrushes using turpentine or thinners.