



HOW TO APPLY MACHINE WAX

MATERIALS NEEDED

- tmbr Machine Wax
- Clean lint-free cloths
- Degreaser or surface cleaner
- Disposable gloves (optional)
- Buffing cloth

STEP 1: CLEAN THE SURFACE

1. Turn off and unplug the machine, if applicable.
2. Remove dust, dirt, grease, and residue from the surface using the degreaser or surface cleaner.
3. Allow the surface to dry completely.

STEP 2: APPLY THE WAX

4. Apply a small amount of machine wax to a clean cloth.
5. Spread a thin, even coat over the metal surface.
6. Avoid excessive buildup.

STEP 3: ALLOW THE WAX TO HAZE

7. Let the wax dry, typically several minutes.
8. A light haze may appear as the wax dries.

STEP 4: BUFF THE SURFACE

9. Use a clean cloth to buff the waxed surface.
10. Continue buffing until the surface feels smooth and slick.



STEP 5: INSPECT COVERAGE

11. Check for missed areas or streaks.
12. Apply an additional thin coat if greater protection is desired.

STEP 6: RETURN THE MACHINE TO SERVICE

13. Ensure all excess wax has been removed.
14. Resume normal use once the surface has been fully buffed.

TIPS FOR BEST RESULTS

- Use only waxes recommended for machine tables and metal surfaces.
- Apply thin coats rather than one thick coat.
- Reapply periodically to maintain rust protection and smooth material movement.

SAFETY

- Keep out of reach of children.
- Clean spills immediately.
- Flammable.
- Dispose of cloths by placing in a bucket of water for a few hours.
- Clean paintbrushes using turpentine or thinners.
- Keep wax away from belts, pulleys, and electrical components.